

Highlander CPL400



	Lifting Height
CPL400	Up to 53"
CPL600	77"
CPL800	101"
CPL1000	125"
CPL1200	149"
CPL1400	171"



Oyster white (standard) or custom RAL color options ensure an attractive blend with building aesthetics.

VERSATILE 4' - 14" LIFTING HEIGHTS

Safe, smooth and economical, Highlander CPL lifts are designed with a top-mounted motor and electrical box to simplify servicing and protect from standing water. The Highlander product line offers an extensive portfolio of accessories to ensure the best and safest fit for your project.

36" x 54"
Non-Skid Platform

750
Pound Capacity

42"
Guard Panels and Rails

CPL400 PRODUCT SPECIFICATIONS

Capacity	750 lb
Speed	10 fpm
Standard Platform	36 x 54 with 42 high guard panels
Footprint Standard Platform	50 x 54 with ramp 50 x 70
Drive	Belt driven ball screw/90 VDC ½ hp motor w/ brake. Optional 24 VDC battery powered unit
Controls	Constant pressure paddle switch with emergency stop
Manual Lowering	Provided
Safety Design	ASME A18.1, Section 2 - Vertical Platform Lifts
Standards	CSA B44.1 / ASME A17.5 - Elevator + Escalator Equipment, ETL Listed 3148125
Safety Features	Safety pan, Final limit, Ball nut safety backup, Belt monitor and Non skid surface
Warranty	2 Year Parts (1-Year on Outdoor units without Outdoor package)



Harmar.com | 800.833.0478

